










BOOT SEQUENCES

WARM BOOT	COLD BOOT	CLEAN BOOT
ELF		
<p>Press and hold the following keys simultaneously</p> 	<ol style="list-style-type: none"> 1. Turn off the Elf by pressing the on-off key. 2. Pull the battery latch down and remove the battery pack. 3. Press the reset button. 4. Insert the battery pack. 5. Turn on the Elf by pressing the on-off key. 	<ol style="list-style-type: none"> 1. Perform a cold boot to Step 4 2. Press and hold down the zero and hang up keys simultaneously 3. Then press on-off key. 4. A dialog box will appear asking for confirmation. Press the Enter Key.
FALCON X3+		
<p>Press and hold the following keys simultaneously</p> 	<ol style="list-style-type: none"> 1. Turn off the Falcon X3+ by pressing the on-off key. 2. Pull the battery latch down and remove the battery pack. 3. Press and hold the scan button and then press the reset button. 4. Insert the battery pack. 5. Turn on the Falcon X3+ by pressing the on-off key. 	<ol style="list-style-type: none"> 1. Perform a cold boot to Step 4 2. Press and hold down the zero and Esc keys simultaneously. 3. Then press the onoff key 4. A dialog box will appear asking for confirmation. Press the Enter Key. 
JOYA GP		
<p>Simultaneously press SCAN + ENTER</p> 	<p>Simultaneously press F1 + F2 + ENTER Or Press with a pin or a paper clip the cold boot button on the back of the mobile computer.</p>	<ol style="list-style-type: none"> 1. Perform a cold boot 2. As soon as the device is rebooting, press simultaneously Esc + ENTER, holding both keys down for few seconds 3. Press ENTER to confirm.
LYNX		
<p>Press and hold the following keys simultaneously</p> 	<ol style="list-style-type: none"> 1. Turn off the Lynx by pressing the on-off key. 2. Slide the battery latch leftward and remove the battery pack. 3. Press the reset button. 4. Insert the battery pack. 5. Turn on the Lynx by pressing the on-off key. 	<ol style="list-style-type: none"> 1. Perform a warm boot 2. Before the splash screen appears, press and hold down the 0 and Telephone End keys simultaneously 3. A dialog box will appear asking for confirmation. Press the Enter Key 
MEMOR X3		
<p>Press and hold the following keys simultaneously</p> 	<p>Press and hold the following keys simultaneously</p> 	<ol style="list-style-type: none"> 1. Perform a cold boot 2. Quickly release all the keys when the screen goes black. 3. With 1 second press and hold the Esc and 0 key until the Clean boot confirmation appears. 4. Release the Esc and zero key. 5. Press 1 to confirm.
RHINO		
<p>Go to the \Windows directory and run the Reboot command. Alternatively, you can remove the upper left panel by removing the 4 screws and reboot by pressing the push button under the cover.</p>	<p>Go to the \Windows directory and run the Cold Reboot command.</p>	<ol style="list-style-type: none"> 1. Perform a warm/cold boot 2. Press and hold down the up and down keys simultaneously on the front of the terminal until the terminal displays the touch calibration screen.
SKORPIO X3		
<p>Press and hold the following keys simultaneously</p> 	<ol style="list-style-type: none"> 1. Turn off the Skorpio X3 Power button. 2. Pull the battery latch down and remove the battery pack. 3. Simultaneously press the SCAN key and the Reset button in the battery compartment. 4. Insert the battery pack. 5. Turn on the Skorpio X3 by pressing the Power button. 	<ol style="list-style-type: none"> 1. Perform a Cold Boot to step 4 2. Press and hold down the 'Esc' + 'Zero' keys simultaneously, promptly after resetting: 3. A dialog box will appear asking for confirmation. Press the Enter Key